### Contents

1	Review circuits	1
	1.1 Ohm's Law	1
	1.2 Kirchoff's Law	2
2	Multiple resistors	2
	2.1 Paralell	2
	2.1 Paralell	3
3	Measuring devices	3
	3.1 Voltmeters	3
	3.1 Voltmeters	3
4	Multiple Batteries	3
	4.1 Series	3
	4.2 Paralell	4

## 1 Review circuits

A circuit is a loop of conductive material



An example of a very boring circuit



A slightly less boring circuit



A circuit with a battery and a resistor



The longer leg of the battery is the negative pole, while the shorter one is the positive pole.

### 1.1 Ohm's Law

Ohm's Law states that  $U = I \times R$  where U is voltage, measured in volts (V), I is current, measured in amps (A), and R is resistance, measured in ohms  $(\Omega)$ .

### 1.2 Kirchoff's Law

Kirchoff's Law states that, at a junction, currents before and after must equal.


$$I_2$$
 $I_1$ 

In this case,  $I = I_1 + I_2$ 

# 2 Multiple resistors

#### 2.1 Paralell

In Paralell, the voltage is the same for all components, but current and resistance may change. In a circuit that looks like this,  $\frac{1}{R} = \frac{1}{R_1} + \frac{1}{R_2}$ 



The following is a proof of this:

According to Ohm's Law,

$$U = I \times R \implies I = \frac{U}{R}$$

$$U = I_1 \times R_1 \implies I_1 = \frac{U}{R_1}$$

$$U = I_2 \times R_2 \implies I_2 = \frac{U}{R_2}$$

According to Kirchoff's Law  $(I = I_1 + I_2)$ 


$$\frac{U}{R} = \frac{U}{R_2} + \frac{U}{R_2}$$

$$\frac{1}{R} = \frac{1}{R_2} + \frac{1}{R_2}$$

This shows that adding a resistor in paralell increases  $\mathbb{R}^{-1}$ , which means that  $\mathbb{R}$  gets smaller.

#### 2.2 Series

In series, the current is the same for all components, but voltage and resistance may change. In a circuit that looks like this,  $R = R_1 + R_2$ .



The following is a proof of this, using Ohm's law.

$$U_1 = I \times R_1$$
 and  $U_2 = I \times R_2$  and  $U_1 + U_2 = U$ 

using Ohm's Law we can now find the resistances by substituting U for  $I \times R$ 

$$I \times R = I \times R_1 + I \times R_2$$

the currents cancel.

$$R = R_1 + R_2$$

## 3 Measuring devices

#### 3.1 Voltmeters

Components in paralell have the same voltage across, thus voltage meters should be connected in paralell with the resistor.

#### 3.2 Current meters

Components in series have the same current flowing through them, thus current meters should be connected in series with the resistor.

## 4 Multiple Batteries

#### 4.1 Series

If there are batteries in series, the voltage adds and current remains the same.

## 4.2 Paralell

If the batteries are in paralell, the current adds and voltage remains the same. This means the batteries will last for longer, or be able to output more current.